



PLUGGING SEWER LATERALS AT BUILDING DEMOLITIONS

NOT TO SCALE

NOTE:

1. EXCAVATE AS NECESSARY AT BACK OF SIDEWALK.
2. INSERT PROPERLY SIZED EXPANSION JOINT PLUG INTO SEWER LATERAL AS INDICATED, 24 INCHES FROM TRUNK SEWER. TIGHTEN WING NUT TO SEAT THE PLUG.
3. FILL SEWER LATERAL WITH STIFF MIX GROUT AS INDICATED.
4. SEAL SEWER LATERAL AT EXCAVATION WITH "BRICKS AND MORTAR" OR WITH SECOND EXPANSION JOINT.
5. BACKFILL AS REQUIRED.
6. PROVIDE INDIVIDUAL INSPECTION REPORT TO CITY ENGINEER AND TO WPCA GENERAL MANAGER.